





WARNING ELECTRICAL SHOCK HAZARD **READ and UNDERSTAND these instructions before installing the luminaire.**

EN EN

Disconnect the Electrical supply power at the services panel (fuse or circuit breaker box). Failure to do so could result in serious injury. Only qualified electricians should install this luminaire and the installation MUST conform to the Canadian Electrical Code Part I, NEC and any local codes and ordinances. Any change or modifications not expressly approved by the party responsible for compliance could void the authority to operate the equipment. Makes sure you have the proper tools and materials to complete

the installation before attempting to install the luminaire.

Disconnect all power to the wiring intended to be connected to the luminaire.

Check the nameplate's marking for more information. Unpack the luminaire.

SURFACE MOUNT (Fig. 1)

1. Use a screwdriver to punch out one of the knocked holes and pass the electrical cable out from the housing.

2. Use the luminaire as a template by placing it on the junction box and penciling in the ceiling the four holes positions. Put the luminaire aside and drill the four holes. Insert an anchoring bolt (not included) into each hole (Fig. 1B).

3. Bring the luminaire close to the junction box. Connect electrical luminaire wires to junction box wires (wire connectors not included) as follows: ground wire to manufacturer's GROUND wire, LIVE wire to manufacturer's power wire, NEUTRAL wire to manufacturer's neutral wire.

NOTE: Push all wires into the junction box.

4. Install the luminaire on the ceiling using the four washers and mounting screws. Tighten securely the screws (Fig. 1B detail).

5. Install the diffuser starting at one end of housing. Insert diffuser slot onto edge of the housing.

Carefully squeeze the diffuser to engage the opposite side with housing. Continue this action down length of diffuser until fully installed onto housing.

6. Turn on the luminaire.



1 SURFACE MOUNT

