

INSTALLATION INSTRUCTIONS

LED Track Light



100% DIMMABLE 100%



GENERAL: All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, contact and obtain the services of a qualified electrician. Use UL or IEC approved wire only for input/output connections.

Remove fixture and mounting components from the box, and make sure that no parts are missing, by referencing the illustration in the illustration instructions.

Turn power off before installation, inspection, or removal.
Use all necessary precautions while performing this procedure.

Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Properly ground electrical enclosure. IT IS IMPERATIVE THAT THE OUTLET BOX BE PROPERLY GROUNDED.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS, OTHERWISE SAFETY WILL BE COMPROMISED.



TROUBLESHOOTING

- Check that line voltage at fixture is correct.
- Ensure that there is voltage at lamp fixture wires. If there is no voltage, then check all connections.
- Check that fixture is grounded properly.

If fixture does not light:

- Check switch to ensure that there are no defects.
- Check fuse/circuit breaker for trips, then check wiring connections.



CLEANING AND MAINTENANCE:

CAUTION: Ensure fixture temperature is cool enough to touch.

DO NOT clean or perform maintenance while fixture is energized.

- Clean lens and fixture with non-abrasive cleaning solution.
- Do not open fixture to clean LED. Do not touch the LED.
- Do not spray liquid directly on to LED, LED driver or wiring.



Five Years Limited Warranty


WARRANTY:

This product is warranted to be free of defect in material and workmanship, for a period of Five years based upon 3 hours usage per day. This warranty starts from the date of purchase by the end user.

PLEASE READ CAREFULLY BEFORE INSTALLING FIXTURE

Save these instructions, as you may need them at a later date.

Figure 1



↓ Please follow these steps for installation. ↓

INSTALLATION INSTRUCTION-TRACK

1. Place track over outlet box and mark position of track mounting holes on ceiling or wall. On wallboard or plaster, drill "5/8" mounting holes.
2. Plain underside of track faces ceiling or wall and slotted side of track faces out to accept lights.
3. Install track to ceiling or wall using toggle bolts (furnished). On wood surfaces use standard #10 wood screws (not furnished).

INSTALLATION INSTRUCTIONS-LAMPHOLDER

CAUTION-Turn off switch at main power source before installing any track or fitting.

1. First, toggle the locking levers at both ends of the light fixture to the "OFF" position, and insert "Adaptor contact" into the slot in the track.
2. Then, toggle the "locking levers" at both ends to the "ON" position. Note: The lamp holder of Grounding tap, polarity side with two pins must point to the track debossed polarity line.
3. If you need to reposition the light fixture, simply toggle the locking levers at both ends back to the "OFF" position to remove the light body, remove to the position then install.
4. After installation is complete, you can adjust the color temperature by toggling the CCT switch as needed, then turn on the power for normal use.
5. During product use, you can freely rotate the lamp body to adjust the illumination direction, with a swing angle of 45° left and right.