

TSBCP4AP instructions

Zone controller


MARNING: May result in serious injury or death. Turn off power at circuit breaker before installing the unit.


FEATURES

- 1. Please call a licensed electrician for installation.
- 2. Drill 1/2" KO in the sheet metal for TSBCP4AP installation, make sure the TSBCP4AP well fixed in the luminaire.
- 3. Screw in the sensor into the receptacle and make sure the connection is tight. Ensure the rubber gasket touches the outside surface of the fixture.
- 4. Attach the lens to sensor and turn the lens module clockwise to ensure it locks in place.
- 5. Please refer below diagram for Wiring.
- 6. Return power back to source.
- 7. Commissioned the sensor via Technilight Smart App.


HOW TO ADD

- 1. Press and hold the Reset button for three seconds until the blue indicator light starts flashing continuously, then release it.
- 2. Add TSBCP4AP to the switch page on the app.





WIRING



Note: PPA104S MAX Load 20A, Sink Current Max.48.5 mA of the dimming port.

TIPS: This Bluetooth device is compatible with Technilight Smart lighting control system only.



TSBCP4AP instructions

Zone controller

How to install Technilight Smart APP?

Download our app:



Technilight Smart Google play Android



Technilight Smart Apple store iOS

WARRANTY INFORMATION

Our company warranties this product to be free of defects in materials and workmanship for a period of five(5) years. There are no obligations or liabilities on the part of our company for consequential damages arising out of, or in connection with, the use or performance of this product or other indirect damages with respect to loss of property, revenue or profit, or cost of removal, installation or reinstallation.